




# Parrot Bebop Drone Upper Parts Replacement

Use this guide to replace the upper assembly on your Parrot Bebop.

Written By: David Hoyt



## INTRODUCTION

Use this guide to replace the upper assembly on your Parrot Bebop. The upper parts include: the ventilator, camera, upper frame, and motherboard.

[video: <http://youtu.be/goDEkjjV5SE>]

---



### TOOLS:

- [T8 Torx Screwdriver](#) (1)
  - [Precision Utility Knife](#) (1)
  - [iFixit Opening Tools](#) (1)
  - [Spudger](#) (1)
-

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-20 03:57:59 PM.